

FLOOD CLEANING CHECKLIST

Special instructions	Dry			Disinfect	General clean			Task	
	dryers if necessary) If applicable to the surface, check the moisture content	solution to provide ongoing protection Ensure the area is thoroughly dry (use	Wipe with clean microfibre cloth (or similar) and clean water	Spray on fungicide and scrub as directed by product packaging	Spray on disinfectant and scrub as dictated by product instructions	Remove sheet materials that have been immersed in water. Dispose of in skip and cover with thick plastic	surfaces clear of any loose material Thoroughly scrub or mop all surfaces using detergent	Remove any surface water	
Remove any mould affected glue									Timber cavity walls
									Concrete
									Metal surfaces
									Brick or concrete block
									Gyprock or Plaster- board
Warning: Use an appropriately licenced professional to remove asbestos - do not attempt to do this yourself									Chipboard or particle board
The underside of lifted tiles should also be disinfected									Fibre or cement sheeting
Sand back areas affected by engrained mould									Ceramic tiles
									Timber floors
									Fixtures and fittings
Cooling coils may need to be cleaned with purpose-made solution									Split system air condition- ers

Need more information? Visit www.qbcc.qld.gov.au or call QBCC on 139 333.